



INSTALLATION INSTRUCTIONS: BROUHARD AIR CLEANER COVER

Part #'s : LF-0012-B, LF-0012- C, WF-0012-B, WF-0012- C

KIT INCLUDES: 1 air cleaner cover, 1 5/16-18X1" stainless bolt

Do not attempt to fit parts to motorcycle unless properly trained. Incorrect fitment may result in injury or death.



1. Loosen the bolt that holds the air cleaner cover in place.



2. Set the Brouhard cover over the stock cover.



3. Tighten supplied mounting hardware with a 1/4 inch allen wrench.



4. ENJOY!

Thank you for purchasing a Brouhard designed product. Extreme care has gone into the design and production. Should you not be 100% satisfied or have any questions, please email us at brouharddesigns@yahoo.com